




KENNECOTT UTAH COPPER SOUTHEAST CORNER

SECTION SE2

Method: GLE

Slip Surface Option: Fully-Specified

Failure Surface A






KENNECOTT UTAH COPPER SOUTHEAST CORNER

SECTION SE2

Method: GLE

Slip Surface Option: Fully-Specified

Failure Surface B






KENNECOTT UTAH COPPER SOUTHEAST CORNER

SECTION SE2

Method: GLE

Slip Surface Option: Fully-Specified

Failure Surface C






KENNECOTT UTAH COPPER SOUTHEAST CORNER

SECTION SE2

Method: GLE


Slip Surface Option: Fully-Specified

Failure Surface D






KENNECOTT UTAH COPPER SOUTHEAST CORNER
SECTION SE3
Method: GLE
Slip Surface Option: Fully-Specified
Description: 2005 Phreatic Conditions
Failure Surface A






KENNECOTT UTAH COPPER SOUTHEAST CORNER
SECTION SE3
Method: GLE
Slip Surface Option: Fully-Specified
Description: 2005 Phreatic Conditions
Failure Surface B






KENNECOTT UTAH COPPER SOUTHEAST CORNER
SECTION SE3
Method: GLE
Slip Surface Option: Fully-Specified
Description: 2005 Phreatic Conditions
Failure Surface C





KENNECOTT UTAH COPPER SOUTHEAST CORNER
SECTION SE3
Method: GLE
Slip Surface Option: Fully-Specified
Description: 2005 Phreatic Conditions
Failure Surface D






KENNECOTT UTAH COPPER SOUTHEAST CORNER

SECTION SE2


Method: GLE

Slip Surface Option: Auto-Search





KENNECOTT UTAH COPPER SOUTHEAST CORNER
SECTION SE3
Method: GLE
Slip Surface Option: Auto-Search






KENNECOTT UTAH COPPER SOUTHEAST CORNER

SECTION SE2

Method: GLE

Slip Surface Option: Fully-Specified

Failure Surface A






KENNECOTT UTAH COPPER SOUTHEAST CORNER

SECTION SE2

Method: GLE

Slip Surface Option: Fully-Specified

Failure Surface C






KENNECOTT UTAH COPPER SOUTHEAST CORNER

SECTION SE2

Method: GLE


Slip Surface Option: Fully-Specified

Failure Surface D






KENNECOTT UTAH COPPER SOUTHEAST CORNER
SECTION SE3
Method: GLE
Slip Surface Option: Fully-Specified
2008 Conditions
Failure Surface A






KENNECOTT UTAH COPPER SOUTHEAST CORNER
SECTION SE3
Method: GLE
Slip Surface Option: Fully-Specified
2008 Conditions
Failure Surface B






KENNECOTT UTAH COPPER SOUTHEAST CORNER
SECTION SE3
Method: GLE
Slip Surface Option: Fully-Specified
2008 Conditions
Failure Surface D





KENNECOTT UTAH COPPER SOUTHEAST CORNER
SECTION SE3

Method: GLE
Slip Surface Option: Auto-Search






KENNECOTT UTAH COPPER SOUTHEAST CORNER

SECTION SE2

Method: GLE

Slip Surface Option: Auto-Search






KENNECOTT UTAH COPPER SOUTHEAST CORNER


SECTION SE2

Method: GLE

Slip Surface Option: Fully-Specified

Failure Surface D





KENNECOTT UTAH COPPER SOUTHEAST CORNER
SECTION SE3
Failure Surface D

